


**Total reset of the BM Uni Line**

Pos.	Description
<p><b>1</b></p>	<p>The power must be off.            Press the 2 buttons (marked with arrows) at the same time while turning the power on.            Now the display will make a count and the Bm Uni Line is reset.  <b>ALL PROGRAMS WILL BE DELETED</b></p>  <p>The diagram shows the control panel layout. At the top is the 'BORUM' logo and 'UNI-LINE EUR 1'. Below is a 5-digit digital display. To the right of the display is a legend for the display indicators: LINE, GAP, TOTAL LINE, TOTAL GAP, SPEED, and HOUR. The main control area contains three columns of buttons: three vertical bars, three 'OFF' buttons, and three vertical bars. To the right is a numeric keypad (0-9) and 'C' and 'E' buttons. At the bottom are three buttons with vertical bars, a 'CUT CYCLE' button, and a 'START STOP' button. Two diamond-shaped buttons with downward-pointing triangles are located on the right side of the panel, one above the numeric keypad and one below it. Arrows point to these two buttons.</p>